






Montagehandleiding Aland



Legs

Support legs



Module

CFV / CFH
arm 15-20cm

2

-

1

CFV / CFH
arm 10cm

2

-

-

C0

-

2

-

HJXH / XVHJ


5

-






-


1st HJXH

2/4



2nd C0





i arm 15/20cm = x1
arm 10cm = x0

