



NBT.BT.0004




Ax1




Bx2






Cx8



Dx8



Ex1



Screw the bolt and waser using wrench

